

Yamaha MOTIF XS Editor V1.3.0 for Macintosh Release Notes

Main Revisions and Enhancements

V1.2.1 to V1.3.0

<New Features>

- Now supports Mac OS X 10.6 Snow Leopard.
- Now supports Yamaha Steinberg FW Driver V1.5.0.
- Reduced the launching time of the Editor.

<Bug Fixes>

- Fixed a problem in which a sound would sustain while using the Virtual Keyboard of Cubase.
- Solved some minor errors.

Version History

V1.1.1 to V1.2.1

- Compatibility with MOTIF XS6/MOTIF XS7/MOTIF XS8 version 1.50 is now enabled.
- Minor bug fixes.

V1.1.0 to V1.1.1

- Solved a problem in which voice data using user waveforms was not copied correctly via Library window operation.
- Solved a problem in which the IEEE1394 device name was not displayed when using the Yamaha Steinberg FW Driver.
- Solved a problem in which the Editor would not go "ONLINE" after changing from IEEE1394 to USB connection.

V1.0.0 to V1.1.0

<New Features>

- It is now possible to edit the Voice parameters in the Voice mode of the MOTIF XS, as well as the Song mode and Pattern mode.
- It is now possible to edit Drum Voices, a feature unavailable in the previous version.
- Compatibility with MOTIF-RACK ES Multi Part Editor files is now enabled.
- The Inc/Dec Action feature has newly been assigned to the list box.
- It is now possible to make settings corresponding to the Utility parameters of the MOTIF XS.
- The order of the parameter categories has been rearranged.

- MIDI note on/off messages transferred to the MOTIF XS are now shown on the virtual keyboard.
- The Assignable Function button is now available at the left of the virtual keyboard.
- The icon for turning the MIDI monitor on/off is now available at the top right of the virtual keyboard.
- The Arpeggio related buttons are now available at the top right of the virtual keyboard.
- The Favorites check box is now available at the right of the Search box in the Voice Library window.
- The Micro Tuning feature is now available in the Global Settings.

<Bug Fixes>

- Solved a problem in which the Voice Library might not close even if you perform the specified operation via the shortcut keys to move the current part from 1 to the "G" row in the Song/Pattern mode.
- Minor bug fixes.

Company and product names that appear in this document are the trademarks or registered trademarks of their respective companies.

(C) 2008-2009 Yamaha Corporation All Rights Reserved.